

STARTER / GENERATOR ASSEMBLY

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
	1012316	STARTER - GENERATOR (INCLUDES ITEMS 1 - 26)	1
1	1013004	ASSEMBLY, ARMATURE (INCLUDES ITEMS 2, 3, 4, 5 AND ARMATURE)	1
2	1013000	SPACER.....	1
3	1013001	SHAFT, BALL BEARING OUTPUT	1
4	1013002	RETAINER, BEARING	1
5	1013005	COMMUTATOR, BALL BEARING	1
6	1013009	SCREW, POLE PIECE	4
7	1013010	ASSEMBLY, FIELD COIL	1
8	1013007	PACKAGE, TERMINAL HARDWARE (F1 AND F2)	2
9	1013017	PACKAGE, TERMINAL HARDWARE (DF)	1
10	1013018	KIT , PULLEY NUT AND SCREW (INCLUDES ITEMS 11 - 15)	1
11	N/A	HEX NUT, M14 x 2.....	1
12	N/A	WASHER, LOCK, M14	1
13	N/A	SCREW, CROSS - RECESSED, M5 x .8 x 18MM (WITH LOCK WASHER AND FLAT WASHER)	3
14	N/A	SCREW, CROSS - RECESSED, M5 x .8 x 16MM (WITH LOCK WASHER)	2
15	N/A	SCREW, CROSS - RECESSED, M4 x .7 x 10MM (WITH LOCK WASHER	4
16	1012999	BELL, OUTPUT SHAFT END	1
17	1013003	KEY.....	1
18	1013013	LEAD, CROSSOVER	2
19	1013011	HOLDER, BRUSH	1
20	1014699	PACKAGE, BRUSH (INCLUDES 4 BRUSHES).....	1
21	1013016	SPRING, BRUSH	4
22	1012990	PACKAGE, TERMINAL HARDWARE (A1 AND A2)	2
23	1012992	BOLT, CLAMP, M6 x 1 x 180MM	2
24	1012993	BELL, COMMUTATOR END	1
25	1012991	COVER, BRUSH INSPECTION PORT	3
26	1017653	COVER, BRUSH INSPECTION PORT, WITH DRAIN	1

G

5